

BRAZE SENTINA



180° coverage

BRAZE ECHO HEAD



45° coverage

FEEDBACK



Audio



Visual



Vibration

POWER



USB battery pack/
USB port



Unplug power source

LIGHTS AND FEATURES



AUDIO SWITCH

Turn beeps on & off



VIBRATION ADJUSTMENT

Adjust strength of vibration

MODE LIGHTS

Indicate which mode is activated

FRONT VIEW WARNING LIGHTS

Indicate location and proximity of front obstacles

REAR VIEW WARNING LIGHTS


Indicate location and proximity of rear obstacles

MODE BUTTON



Short range Long range

Push twice to turn off all feedback



3.5MM JACK

For buddy button and other alternate controls to toggle between modes

SHORT RANGE MODE




2' / 60cm*

1' / 30cm*

- Manoeuvring
- Tight spaces

COVERAGE ZONE



LONG RANGE MODE



4' / 120cm*

2' / 60cm*

- Moving quickly
- Unfamiliar spaces

*distances can be customised



OBJECT IN BLIND SPOT



BACKING OUT OF ELEVATORS



BACKING THROUGH DOORWAYS



Object close to rear right side



The door is closed



Too close to the left!



Object/ person coming up directly behind you



The door is open



Well aligned in doorframe